

**Owner's Operating Instructions** 



Congratulations! You have purchased one of the most sophisticated cordless telephones on the market! The AUDIOVOX DT 921c has been designed to offer a new standard in cordless telephone technology.

Unlike most other cordless phones, the AUDIOVOX DT 921c digitizes' your voice using advanced ADPCM digital voice coding to provide noise and distortion free performance. In most conditions you will not be able to tell you are using a cordless phone. Gone are the annoyances of static, interference and having to listen to other people's conversations on your cordless phone.

The AUDIOVOX DT 921c scrambles your voice before it transmits it. This allows you the security of knowing that no one can tune in and eavesdrop on your conversations.

The AUDIOVOX DT 921c decodes and displays name and/or number Caller ID (CID) information where available and when subscribed to. The alphanumeric display can show both the name and number of the calling party. Up to 24 name characters or 11 phone number digits can be displayed on the LCD.

With the AUDIOVOX DT 921c, the user can easily answer a call by pressing any key other than the OFF, MUTE or VOLUME Keys. In addition, the handset keypad and LCD illuminate while the handset rings to signal an incoming call. This is very useful in a dark environment. The AUDIOVOX DT 921c also provides a one-way Page/Find. Pressing the base PAGE key will cause the handset to ring in a manner which distinguishes it from normal incoming ringing. This can be used to alert the handset user, or to simply locate the handset in the event that it is misplaced.

The AUDIOVOX DT 921c uses special memory in both the base and handset which is not susceptible to power failures. This provides permanent storage of all memory dial numbers, CID information as well as the base and handset security codes.

When an optional battery pack is installed in the base unit, the AUDIOVOX DT 921c uses this battery pack to provide operational backup in case of power failure. In this way you have access to all normal phone functions during a total power outage. Calls can still be placed and received without interruption. More than 5 hours backup will be possible with a fully charged battery pack in the base unit.

The AUDIOVOX DT 921c informs you that another extension is currently in use on the same phone line. The phone will also alert you when you are Out of Range, even when you're not using the phone!



# 

# SPECIAL FEATURES

- 900 MHz Operation.
- Fully Digital Link between Handset and Base with ADPCM voice coding.
- Digitally-Scrambled Voice Communication.
- · Name / Number CID display.
- 2 row by 12 character 5x7 dot matrix alpha-numeric LCD.
- 50 CID memory locations.
- · Backlit LCD; on the handset.
- · Backlit handset keypad.
- 20 location Programmable Memory for 20 Digit Phone Number.
- 10 Channel Operation with auto channel selection.
- Out-of-Range indication while the handset is in use or in standby mode.
- · Removable handset battery pack.
- Spare battery charger in the base unit.
- Complete battery back-up in case of power failure (with optional spare battery pack installed in base).
- Face-up Handset charging.

- Easy answer When the phone rings, simply press any key other than OFF, MUTE, or the Volume Keys on the handset to answer.
- Auto hang up when returning the handset to the base cradle.
- Extension in use indicator.
- · 24 Bit Digital Security Code.
- DTMF and Pulse Dialing.
- Low Battery Detect and Warning indicator.
- Up to 7 hours continuous talk time or 7 days standby time.
- Volume Adjust on Handset.
- REDIAL, HOLD, PAGE and MUTE.
- Hearing-Aid Compatible Receiver.
- Detachable power supply.
- Non-volatile storage of security code and memory dial records.
- Programmable Ringer Types.

This manual is designed to make you familiar with the AUDIOVOX DT 921c. We strongly recommend you read the manual before using your phone.



DT 921





This equipment complies with Parts 15 and 68 of the Federal Communications Commission (FCC) rules for the United States. It also complies with regulations RSS210 and CS-03 of Industry and Science Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

A label is located on the underside of the base unit containing either the FCC registration number and Ringer Equivalence Number (REN). You must, upon request, provide this information to your local telephone company.

This equipment is compatible with inductively coupled hearing aids.

Should you experience trouble with this telephone equipment, please contact:

AUDIOVOX COMMUNICATIONS SERVICE DEPT. at (800) 229-1235.

For repair/warranty information. The telephone company may ask you to disconnect this equipment from the line network until the problem has been corrected.

### FCC Part 15

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliances could void the user's authority to operate the equipment.

The equipment has been tested and found to comply with part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between\_ the equipment and receiver.
- Connect the equipment into an outlet or on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.





#### FCC Part 68

The FCC requires that you connect your cordless telephone to the nationwide telephone network through a modular telephone jack (USOC RJ11C, RJ11W).

Your telephone company may discontinue your service if your equipment causes harm to the telephone network. They will notify you in advance of disconnection, if possible. During notification, you will be informed of your right to file a complaint with the FCC.

Occasionally, your telephone company may make changes in its facilities, equipment, operation, or procedures that could affect the operation of your equipment. If so, you will be given advance notice of the change to give you an opportunity to maintain uninterrupted service.

The base unit contains no user serviceable parts. The handset contains a user replaceable battery pack.

If it is determined that your telephone equipment is malfunctioning, the FCC requires that it not be used and that it be unplugged from the modular jack until the problem has been corrected. Repairs to this telephone equipment can only be made by the manufacturer or its authorized agents or by others who may be authorized by the FCC. For repair procedures, follow the instructions outlined under the AUDIOVOX Limited Warranty. This equipment may not be used on coin service provided by the phone company or Party Lines.

The REN is useful in determining the number of devices you may connect to your telephone line and still enable the devices to ring when you receive a call. The general rule is that the REN value should not exceed 5.0A total; however, contact your local telephone company for the specific number in your area.

IC (Industry Canada)

This telephone is registered for use in Canada.

- Notice: The REN assigned to this device denotes the number of devices you may connect to the telephone loop which is used by the device to prevent overloading The termination on a loop may consist of any combination of devices subjected only to the requirement that the sum of the REN does not exceed five (5.0)
- Notice: The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational and safety requirements. The Department does not guarantee the equipment will operate to the user's satisfaction.



Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of services in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas. Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electrical inspection authority, or electrician, as appropriate.

Your AUDIOVOX DT921c is designed to operate at the maximum power allowed by the FCC. This means your handset and base unit can communicate only over a certain distance which will depend on the location of the base unit and handset, weather, and the construction and layout of your home or office.





When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- Read and understand all instructions.
- Follow all warnings and instructions marked on the product.
- Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
- Do not use this product near water (for example, near a bath tub, kitchen sink, or swimming pool).
- Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product.
- 6. Slots and openings in the cabinet and the back or bottom are provided for ventilation. To protect it , from overheating, these openings must not be blocked by placing the product on the bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heat register. This product should not be placed in a built-in installation where proper ventilation is not provided.

- This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
- Do not allow anything to rest on the power cord. Do not locate this product where the cord will be abused by persons walking on it.
- Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a risk of fire or electric shock. Never spill liquid of any kind on the product.
- 10. To reduce the risk of electric shock, do not disassemble this product, but take it to a AUDIOVOX authorized service facility. Opening or removing cabinet parts other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the appliance is subsequently used.
- Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.

\$15/98, 11:13 AM



- 12.Unplug this product from the wall outlet and refer servicing to a AUDIOVOX authorized service facility under the following conditions:
  - A. When the power supply cord or plug is damaged or frayed.
  - B. If liquid has been spilled into the product.
  - C. If the product has been exposed to rain or water.
  - D. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, because improper adjustment of other controls may result in damage and will often require extensive work by a VTech authorized technician to restore the product to normal operation.
  - E. If the product has been dropped and the cabinet has been damaged.
  - F. If the product exhibits a distinct change in performance.

- 13.Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lighting.
- 14.Do not use the telephone to report a gas leak in the vicinity of the leak.

AUDIOVOX COMMUNICATIONS SERVICE DEPT. at (800) 229-1235.

# SAVE THESE INSTRUCTIONS




# CHARGING ATHE HANDSET BATE

The handset of your AUDIOVOX DT921c cordless telephone is powered by a rechargeable battery pack. It charges automatically whenever the handset is in the base. You should charge the battery pack for 16 hours when you first receive your phone. You'll know the battery pack needs charging when:

 The phone emits a warning tone when you press the TALK key.

The low battery message is displayed:



The handset seems completely dead, the LCD is clear and the handset does not beep when you press the keys.

To Charge The Battery Pack

To charge the battery pack, place the handset in the base unit. The CHARGE indicator will light to show the handset is seated properly and the battery pack is charging. It is recommended that the battery pack be charged for at least 16 hours initially and 8 hours for maintenance charging. You can use your telephone before that with diminished capacity, but it is best to charge the battery pack fully. It will take several recharge cycles to maximize the charge capacity of your battery The maximum battery life pack. between charges is 7 hours of continuous talk time or 7 days of stand by.

Alternatively, if you have purchased a spare battery pack and it has been charging in the base unit, simply exchange the drained handset battery pack with the fully charged replacement battery pack from the base charger. Place the drained handset battery pack into the base charger to recharge.


The base spare battery charger does NOT charge a battery pack as quickly as the handset battery charger. A full charge requires 24 hours when using the spare battery charger.

TESTIMPOSSIBLE TO SOVER-CHARGETHE BATTERCPACK The battery pack can be recharged many times, but if you get a low-battery signal even after 16 hours of charging in the base cradle (or 24 hours in the base spare battery charger), the battery pack(s) should be replaced.

To purchase replacement battery packs, call AUDIOVOX Communications at (800) 229-1235

A WORD ABOUT RECHARGEABLE BATTERIES

However, to maximize the life of your battery pack, do not return your DT921c Handset to the Base Unit cradle for recharging until the LOW BATT LED begins to flash.



dt921.p65

10

10

1998/6/23, AM 10:32

4. Exercise care in handling batteries in order not to short the battery with conducting materials such as rings, bracelets, and keys. The battery or conductor may overheat and cause burns.

G

los purchases replacement@battery packs, call AUDIOVOX Communica tions at (800) 229-1235


# SPARE BATTERY CHARGER

The DT921c has a built-in spare Battery Charger, which is located in the cradle of the Base Unit.


NOTE an order to benefit from this feature you must obtain an optional. Spare Battery from and Audiovox authorized idealer or by contacting Audiovox Customer Service af (800) 229 1235 in theat S'A.

## Installation

Remove the Spare Battery charger cover by pressing the release tab and lifting up.



Place a battery pack in the Spare Battery charger. Make sure the metal charging contacts on the underside of the battery pack are aligned with the charging contacts in the Spare Battery charger.



#### Power Backup


When a Spare Battery pack is installed in the Base Unit, the AUDIOVOX DT921c uses this battery pack to provide operational backup in case of a power failure. If you have a fully charged battery pack in the Spare Battery pack charger and there is a power outage; you will still be able to place and receive calls for up to five hours.

### Replacing a Drained Handset battery

The Spare battery pack can also be used to replace a drained Handset battery pack to ensure uninterrupted use. Be sure to put the drained battery pack in the Spare Battery charger for recharging.

Please note that the Spare Battery compartment charges at a slower rate than a battery pack charging in the Handset. It takes 24 hours to fully charge a battery pack in the Spare Battery charger.


н



Setting Up Your AUDIOVOX DT921c Choose an area near an electrical outlet and a telephone wall jack.

### AC Power Adaptor

Plug the AC power adaptor into an electrical outlet and the DC connector to the back of the base unit.





#### A CAUTION:


Use only CLASS 2 9V DC POWER SUPPLY included with your phone.

# Handset Ringer

The handset ringer is programmed ON as the factory default setting. Refer to PROGRAMMING THE RINGER on page 21 for more information.


## Setting the Tone/Pulse Switch

The TONE/PULSE switch is located on the bottom of the base unit and is factory set to TONE. If you have touch tone service, do not change the switch setting. If you have rotary (Pulse) service, set the switch to PULSE.



Charge the handset battery pack before use. The battery pack recharges automatically whenever the handset is in the base unit. The batteries must be charged for 16 hours before using your phone for the first time.

Connect Telephone Line Cord Plug one end of the telephone cord into a wall jack and the other end into the back of the Base Unit.






ī

Check for a dial tone. After the battery pack is charged, rotate the Base Unit antenna to an upright position. Pick up the Handset and press TALK "PHONE ON" will appear on the LCD, and you will hear a dial tone. If not, see 'IN CASE OF DIFFICULTY' on page 33.

Fill in the telephone number card on the base unit.



# CAUTION:

ᠼ

- 1. Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- 4. Use caution when installing or modifying telephone lines.

dr921.p65

13

13

J.



Ð.





# USING THE WALL MOUNT ADAPTOR

 Position the wall mount bracket on the base.

Line up the tabs on the wall mount adaptor with the holes on the bottom of the base (Figure 1). Snap the wall mount bracket firmly in place.

- Mount the base on the wall. Position the base so the mounting studs will fit into the holes on the bottom of the base. Position the power cord to extend down the wall the phone is to be mounted on. Slide the base down on the mounting studs until it locks into place.
- Connect the telephone line cord. The telephone line cord has a snap-in plug at each end. Insert one of the plugs into the jack on the bottom of the base. Insert the other end of the plug into the wall jack.
- Plug the AC adaptor into an electrical outlet and the DC connector into the power jack located on the back of the Base Unit.




Figure 1




Figure 2


 $\odot$ 

\$15/98, 11:13 AM




LCD DISPLA

LCD Display Messages




the PHONE ON indicator is displayed when the phone is in use.







shows the handset volume setting.




is displayed when the unit is in a lowbattery condition. The handset typically operates for at least 5 minutes after the low battery indication first appears.



is displayed when the Base Unit pages the handset.



is displayed when the handset is on hold.




is displayed when the handset microphone has been muted.



is displayed when the handset ringer has been programmed off.



is displayed when the handset has lost communication with the base unit and is attempting to reestablish a link by scanning all channels.




is displayed if communication with the base is reestablished.

EX1	ENSION	
IH	USE	

is displayed while in OFF mode, if another phone is currently using the same line.

15

OT 921



# THE HANDSET FEATURES


16


0

5/15/98, 11:13 AM

16

DT 921





# THE BASE UNIT FEATURES

17

-6

17

5/15/90. 11:13 AM



# SET-UP

- Plug AC adaptor into a standard electrical outlet and Base Unit
- Set Dial Mode switch to PULSE or TONE. The unit is factory set to TONE.
- Let the handset battery pack charge for 16 hours before first use.
- Connect telephone line cord to base unit and telephone jack.

# MAKING CALLS

 Press the TALK key. When the "PHONE ON" indicator is displayed and you hear a dial tone, dial the number.

OR Enter the number to be dialed on the LCD and then press the TALK key.

# ANSWERING CALLS

 To answer a call, press any key other than OFF, MUTE, or the Volume Keys. The handset will NOT auto-answer when lifted off the base cradle.

## HANGING UP

 Press OFF or place the handset in the cradle to hang up a call.

# TO PLACE A CALL ON HOLD

 Press HOLD on the handset to place an active call on hold.
Press HOLD again to return to the call.

### TO MUTE A CALL


- Press MUTE to disable the handset microphone.
- Press MUTE again to return to normal two way conversation.

# TO PAGE THE HANDSET

- To page from the base, press PAGE.
- To cancel the PAGE either press PAGE again on the base or press OFF on the handset.

#### STORING MEMORY (SPEED) DIAL. NUMBERS:

- The phone should be OFF.
- Enter the number you wish to store on the LCD up to a maximum of 20 digits.



- Press PROG . The LCD will display "PROGRAM LOCATIONL."
- Enter a two digit memory location (01 .. 20), the unit will store the number, emit a happy tone to confirm successful programming and exit program mode.

\$1598, 11:13 AM





Press the TALK key.

Press MEM .

Enter the memory location of the phone number you wish to dial (01...20). The number will be displayed on the LCD and will be dialed.

# CIDECALLERID

 To view information stored in CID memory, press CID on the handset.



The display will show the most recent call received.

To view the time and date of the call press and hold the 7  $\oplus$  key. The time and date will be shown along with the phone number. You will see something like:

503-6	43898	.1 1 1
8:379	augs	Ĩ

As long as the key is held down.

 To view other calls, scroll backwards and forwards by using the ∆ (\*) and ▽ (\*) keys.

To view additional digits not shown on the display, press the  $\rightarrow$  (9) key

3

· To exit press OFF.

# USING REDIAL

 Press the TALK key, then REDIAL to automatically redial out the last number you dialed.


Or

 Press REDIAL so that the number is shown on the display and then press the TALK key.

HOLD

- Press HOLD to put a call on hold.
- To return to the call, press HOLD key again





MAKING CALES You can make calls directly from the handset whether you are at the base or away from it.

NOTE: There are two different ways to dial a number:

Press the TALK key and wait for dial tone. Then dial the number you want.

Or

 Enter the number onto the display first, then press the TALK key. This will dial the number that is displayed on the LCD after 2 seconds. See "ADVANCED DIALING" on Page 22

If you make a mistake when dialing, press OFF to hang up, then press the TALK key to get the dial tone again.

To end a call, either place the handset back in the base, or press OFF on the handset.

ANSWERING CALLS When the Handset rings, press any key other than OFF, MUTE or the VOLUME keys to answer your call.

VOLUME: CONTROES The volume controls for the handset are located on the side of the unit. Press the ▲ (up) or V (down) keys to increase or decrease the volume. Holding either key down will continuously change the volume setting. The earpiece volume level indicator on the LCD will change accordingly. There are four volume levels. FLASH

You can use your AUDIOVOX DT921c cordless phone with services such as Call Waiting. Simply press the TALK key to FLASH the line.

REDIAL the last number you dialed, press the TALK key, then press REDIAL . The phone will automatically dial the number. The number will be shown on the display.

CLEARING THE DISPLAY The display can be cleared by pressing and holding the CLR/DEL key down until the display clears.

- Press MUTE during conversation to disable the handset microphone.
- Press MUTE again to return to normal operation.

RINGER MUTE


 Press MUTE during incoming ringing to disable the ringer for the duration of the call.

HOLD Press HOLD to place an active call on hold. The LCD will display CALL ON HOLD. Press HOLD again to return to the call.

# PAGE/HANDSET LOCATOR

- To page from the Base Unit, press PAGE.
- The LCD will display BASE PAGING HANDSET.

To cancel the page, either press PAGE again on the Base Unit, or press OFF on the Handset.




### CALL WAITING

While you are on a call, you will hear an alert signal, warning that a second caller is trying to reach you. CALL WAITING is a subscription service, available from most local telephone service providers. Contact your provider for details.

If you subscribe to this service linked with CALLER ID (CID), the name and/ or phone number of the second caller can be displayed on the LCD immediately after hearing the CALL WAITING alert. For more details, see CID CALLER ID

Switching calls using FLASH


- To switch over to the new call, press the TALK key; the first call is put on hold.
- To switch back to the first call, press the TALK key again.



#### **Temporary Tone**

If you have rotary (dal pulse) telephone service (TONE/PULSE switch is set to PULSE), this feature allows you to temporarily switch to TONE dialing for such purposes as remote access to answering machines, bankby-phone services, use of calling cards and other special services. First, dial the call normally. Then activate the Temporary Tone feature by pressing TONE (the \* key). You can then press the numbers or symbols you need, and your phone will send the proper signals.


To end the call, press OFF or place the handset back in the base. The phone will automatically go back to rotary (dial-pulse) service.



Programming The Ringer § The handset ringer is capable of four different types of ringer tones. The following sections detail how to select different ringer types and how to turn off the handset ringer.


21

5/15/98, 11:13 AM




Changing Ringer Types To program, the handset must be OFF.

To select a different ringer type do the following:




Press: PROG Press: # Press: 1 for ringer type 1 2 for ringer type 2 3 for ringer type 3 4 for ringer type 4

The handset LCD will show the ringer type selected, for example




Press PROG or OFF to exit.

Turning Off The Ringer To turn off the ringer do the following:



Checking The Ringer Type : To test the present ringer type, do the following:




Press PROG or OFF to exit.

CLR/DEL Key Function The CLEAR and DELETE functions can be accessed separately depending on how long the key is held down. For example, to clear the last digit entered on the display, press the CLR/DEL key for less than 1 second. Press and hold the CLR/DEL key for more than 1 second to completely clear the LCD.

The delete function is also used to delete CID and memory dial records, see DELETING STORED NUMBERS, and DELETING NUMBERS.

\$/15/98, 11:13 AM



### Advanced Dialing

There are two different ways to dial a number:

- Press the TALK key and wait for a dial tone. Then dial the number you want either manually, using MEMORY (MEM) dialing, CID dialing or REDIAL.
- Enter the number you wish to dial on the display first. Then press the TALK key. This will dial the number which is displayed on the LCD after 2 seconds.

NOTE: The phone will dial any number which is shown on the display. If you do not want to dial the number shown on the LCD, it can be changed by:

Press and hold CLR/DEL until the display is cleared, then dial normally.

Or Press OFF and start over.



23

5/15/96, 11:13 AM




Storing Memory (Speed) Dial numbers To program a speed dial location, do the following:

With the phone OFF, enter the telephone number you wish to store. (20 Digits Maximum).

Enter program mode by pressing PROG. The display will show the following:



Enter the memory location (01..20) you wish to store the number in. As soon as the second memory location digit is entered, the unit will emit a happy tone (a short series of beeps) to confirm successful programming and exit program mode.



If programming is unsuccessful the unit will display:

# PROGRAMMING INCOMPLETE

Unsuccessful programming can result from not correctly completing the programming sequence. For example, if after entering a number on the LCD and entering program mode, the OFF key were pressed instead of entering a valid memory location, the "PROGRAMMING INCOMPLETE" message would appear. If this message appears, simply repeat the programming sequence.

Sfeed Dior Loco Two




Ŷ

# Dialing From Memory

Press TALK to get a line.

Press MEM , you're prompted to enter a speed dial location number:




- Enter a 2 digit location number (01-20)
- The number stored in that location will be displayed and immediately dialed.
  Or

Beginning from the OFF mode, press MEM followed by a 2 digit location number (01-20).

Press MEM again to exit memory dial mode and leave the number on the display.

Note that if digits were on the display prior to entering memory dial mode, the contents of the speed dial memory will be appended to those digits. For example, if 1503 was on the LCD and the contents of the memory location is 6438981, then the display would show the following upon exiting memory dial mode:



Press TALK, the number on the display will be dialed after a 2 second pause.

# NOTE:

The ability to temporarily add memory contents to digits already entered on the display operates in the same way for CID and speed dial memories.

In this way, long distance and area codes (for example, 1503) can be entered on the LCD and can preface numbers recalled from CID memory before dialing. This is important because only the last 7 digits of any number are displayed when dialing from CID memory.

### Changing Stored Numbers

To change or replace a stored number simply enter the new number on the display and store it in the memory location you wish to change.

# Deleting Stored Numbers

- Press MEM . The display will change to "SPEED DIAL LOCATION\_\_".
- Enter memory location number (01-20).
- Press CLR/DEL key. The display will change to "LOCATION XX
- DELETED".



Press OFF to exit.

# NOTE:

25

Stored numbers are retained in memory even if the base loses its power or the handset battery is removed.

÷,



# Storing Special Codes

To insert a pause in a phone number, press HOLD at the appropriate point when entering the number on the LCD. This inserts a 2 second pause. A " P " appears in the display to show the pause. For longer pauses, press HOLD two or more times. Each press makes the pause 2 seconds longer and is treated as a stored digit.

If your phone is connected to a PBX, you can store the PBX access number and a pause before the phone number. For example, to store 9-PAUSE-555-1234 in memory location 08, do the following:


- 1. Press
- 9 2. Press HOLD
- 3. Dial 5551234
- 4. Press PROG
- 5. Enter 08







49) 梁



However, when you dial directly from CID memory, only the last 7 digits of the received telephone number will be used. Consequently, you would actually dial this:


The AUDIOVOX DT921 was designed to accommodate this situation. If you need to temporarily add a long distance prefix and /or area code (such as 1503) before the CID number, do the following:

 Beginning from the standby mode, key in the necessary digits, your display will look like this;

1503

Then, to temporarily add the last 7 digits only from a CID memory, press CID.

- Using the △ (\*) and ♥ (#) keys, scroll through the received calls to locate the number you wish to dial.
- Once you have located the number you wish to dial, simply press TALK key. The last seven digits will be added to the numbers already in the LCD, and the whole number shown below will be automatically dialed.



# Special Message Indicators

If for any reason the telephone number of the caller is unavailable, or if the caller is outside the CID service area, the message UNAVAILABLE is displayed on the LCD.

# UNAVAILABLE


If the caller has exercised the option to block his or her number from being sent, then the display will show PRIVATE.

PRIVATE

If an error is detected, then the CID information is incomplete and will not be displayed. "TRANSMISSION ERROR" will be displayed on the LCD screen.

# TRANSMISSION ERROR


The occasional appearance of "TRANSMISSION ERROR" on your display does not indicate a problem with your unit or your telephone line. However, if this appears frequently, you may want to notify your telephone company.



### **Reviewing Numbers**

Calls stored in memory can be reviewed by pressing CID. The display will show the number of the most recent (CALL #01). The top line of the display is used to indicate the memory location number and the bottom line of the display shows the name, see below:

There may be additional characters in the name which can not be shown on the current display. Press the  $\rightarrow$  (9) key. This will overwrite the CID memory location on the top line to show up to a maximum of 15 alpha characters for the duration of the key press. The first 12 alpha characters will be on the top line with up to 3 additional characters on the second line. To find out the corresponding phone number as well as the date and time of the call, press and hold the 7  $\bigcirc$  key. The date and time will be shown. Releasing the key will again show the caller's name.




Pressing the ( $\Delta$  (\*) key) displays the next lower in sequence call record. Likewise, pressing the ( $\nabla$  (#) key) displays the next higher in sequence) call record. The higher the call number, the older the call.

To save you time in reviewing call records, you can "wrap-around" the call history log. For example, if you press the  $\triangle$  (\*) key enough to scroll back to the first record, pressing it again will force the display to go to the very end of the call record.



ABC COMPANY LTD		
	REVIEWING NUMBERS PRESS Press the = a and # 0 keys to scroli Press and hold the 7@ to view number Press Press or to exit	

29



2.

DELETING NUMBERS Pressing the CLR/DEL button deletes the CID number displayed.

 While the phone is in CID mode, press the CLR/DEL key once to delete the current call and the display will show:



The older CID records will be moved forward by one location .

 Press and hold the CLR/t/time for more than 2 seconds v, the the entire contents of CID the The display will show the type for a final confirmation, by entire CID memory is ensure

DELE	ETE	ALL
DEL	ΤO	ALLS

DELE	ET IN(	E
ALL	CALL	_S



A States

-----

OT 921





# NOISE OR INTERFERENCE.

Your AUDIOVOX DT921c cordless telephone has auto-channel scan circuitry which will detect excess noise and change the channel of the phone to reduce it. This is done automatically.

Since the AUDIOVOX DT921c is a fully digital phone, it does not suffer from noise associated with regular cordless phones. At times you may experience occasional "drop outs", especially at the extreme edges of the phone's range. Simply move closer to the base unit and this will disappear.

### AUTOMATIC SECURITY CODING

Your AUDIOVOX DT921c phone is factory set with 16.8 million possible security codes. This unique security code allows your handset and base to recognize each other, and minimizes the possibility of another cordless phone using your telephone line.

# OUT OF RANGE INDICATION

If the handset is moved to a point where the base and handset can no longer communicate, the handset will make a quick series of beeps to signal Out of Range.

If the handset is active when taken out-of-range, it will beep twice a second and enter standby mode after 25 seconds if the link is not reestablished. If the handset is brought back within range, it will automatically re-link.

For out-of-range in standby mode, the handset will beep once and then at 15 second intervals, will display "CHANNEL SERACHING" on the LCD, and scan all channels in an attempt to re-link with the base.

# CHANNEL SEARCHING

OUT OF RANGE WHEN PHONE IS

If you are presently engaged in a phone conversation move closer to the base. If the base unit does not communicate with the handset within 25 seconds of losing contact, it will automatically hang up.

OUT OF RANGE WHEN PHONE IS OFF

If the phone is OFF, the handset and base still monitor each other to make sure that they can communicate. If the handset is moved out of range, the handset will make a series of beeps, and will then display "CHANNEL SERACHING" on the LCD. At 15 second intervals the handset will scan all channels in an attempt to reestablish communication with the base. This process does not require user intervention; the handset will re-link with the base automatically once it is brought back within range. The unit will then be able to receive and place ..... calls.

When the base unit is unplugged from the power supply, the handset will give the "Out of Range" warning beep. Plug the base in again and this will stop.



OT 921

31



### TAKING CARE OF YOUR TEL-EPHONE.

Your AUDIOVOX DT921c cordless telephone contains sophisticated electronic parts, so it must be treated with care.

### Avoid rough treatment

Place the handset down gently. Save the original packing materials to protect your telephone if you ever need to ship it.

### Avoid water

Your telephone can be damaged if it gets wet. Do not use the handset outdoors in the rain, or handle it with wet hands. Do not install your base unit near a sink, bathtub or shower.

#### Electrical storms

Electrical storms can sometimes cause power surges harmful to electronic equipment.

For your own safety, use caution when using electric appliances during storms. Cleaning your telephone Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a soft cloth slightly dampened with water or a mild soap. Do not use excess water or cleaning solvents of any kind.

Remember that electrical appliances can cause serious injury if used when you are wet or standing in water. If your base unit should fall into water, DO NOT RETRIEVE IT UNTIL YOU UNPLUG THE POWER CORD AND TELEPHONE LINE CORDS FROM THE WALL. Then pull the unit out by the unplugged cords.



Seren Stratter

- 00-00

32

DT 921



\$/15/98, 11:13 AM



If you have difficulty operating your phone, the suggestions below should solve the problem. If you still have difficulty after trying these suggestions, call AUDIOVOX Communications at (800) 229-1235.

THE PHONE DOESN'T WORK AT ALL.

- Make sure the Power Cord is pugged
- Make sure the telephone line cord is plugged firmly into the base unit and the telephone wall jack.
- Make sure the batteries are properly charged. If the 'LOW BATTERY' message is shown, the battery pack needs charging.

NO DIAL TONE.

- First check all the suggestions above.
- If you still don't hear a dial tone, disconnect the base unit from the telephone jack and connect a different phone. If there is no dial tone on that phone either, the problem is in your wiring or local service. Call your local telephone company.

YOU GET NOISE, STATIC, OR A WEAK SIGNAL EVEN WHEN YOU'RE NEAR THE BASE UNIT.

 Household appliances plugged into the same circuit as the base unit can sometimes cause interference. Try moving the appliance or the base unit to another outlet.

YOU GET NOISE, STATIC, OR A WEAK SIGNAL WHEN YOU'RE AWAY FROM THE BASE UNIT.

- You may be out of range. Either move close to the base, or relocate the base unit.
- The layout of your home may be limiting the range. Try moving the base unit to another position.

### THE HANDSET DOES NOT RING WHEN YOU RECEIVE A CALL.

- Make sure you have the handset ringer activated. To set the ringer, see "PROGRAMMING THE RINGER".
- Make sure the telephone line cord is plugged firmly into the base unit and the telephone jack. Make sure the power cord is plugged in.
- You may be too far from the base unit.
- You may have too many extension phones on your telephone line to allow all of them to ring. Try unplugging some of the other phones.

YOU HEAR OTHER CALLS WHILE USING YOUR PHONE.

 Disconnect your base unit from the telephone jack, and plug in a regular telephone. If you still hear other calls, the problem is probably in your wiring or local service. Call your local telephone company.

YOU HEAR NOISE IN THE HANDSET, AND NONE OF THE KEYS OR BUTTONS WORK.

#### COMMON CURE FOR ELECTRONIC EQUIPMENT

Electronics, like people, can sometimes get confused. If the unit does not seem to be responding normally, then try putting the handset in the cradle. If it does not seem to respond after trying this a few times, do the following (in the order listed):

- 1. Disconnect the power to the base.
- 2. Disconnect the handset battery.
- 3. Wait a few minutes.
- Connect power to the base.
- 5. Connect the handset battery.
- Put the handset in the base.





FREQUENCY CONTROL Crystal Controlled Dual PLL Synthesizer

# TRANSMIT FREQUENCY

- Handset: 925.05 MHz to 927.75 MHz ( All ten channels within this range)
  - : 902.3 MHz to 905.0 MHz (All ten channels within this range)

# RECEIVE FREQUENCY

- Handset: 902.3 MHz to 905.0 MHz ( All ten channels within this range)
- Base : 925.05 MHz to 927.75MHz ( All ten channels within this range)

NOMINAL EFFECTIVE RANGE Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use.

# SIZE

Handset: 18.7x6.25x4.1cm (L x W xT) Maximum (Antenna excluded)

> 21.9x14.4x6.4cm (L x W x T) Maximum (Antenna excluded)

WEIGHT Handset: 250 grams Base : 415 grams

### POWER REQUIREMENTS

Handset: Self-contained nickel-cadmium rechargeable battery supply, 3.6V nominal. 600mAh capacity.

Base: 9VDC @ 300mA

#### MEMORY

- Speed Dial:20 Memory locations, 20 digits per location.
- CID : Alpha Numeric Display 50 Memory locations

(Ne. ( 1 + h 12 m 3

SPECIFICATIONS ARE TYPICAL AND MAY CHANGE WITHOUT NO-TICE.





34



AUDIOVOX CORPORATION (the Company), warrants to the original retail purchaser of this Audiovox Telephone, that should this product or any part thereof (except the items listed below), under normal use and conditions, be proven defective in material or workmanship within the first twelve (12) month period from the date of purchase, such defect(s) will-be repaired or replaced (with new or rebuilt parts) at the Company's option, without charge for parts or labor directly related to the defect(s).

The accessories consisting of the antenna and adapter are similarly warranted for twelve (12) months from original purchase.

This Warranty does not apply to batteries, or costs incurred for testing or checking, or to any product or part hereof which has suffered through alteration, serial number defacement, improper installation, excessive temperature or humidity, environmental conditions, mishandling, misuse, neglect or accident. This Warranty is not assignable or transferable.

To obtain repairs or replacement within the terms of this Warranty, the product should be delivered with proof of purchase, specification of defect(s), transportation prepaid, to the Company at the address shown below.

Call toll free to (800) 229-1235 (in N.Y.State, (516) 233-3410) for reference to an Authorized Warranty Station in your area.

THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

Quaningut

# **TABLE OF CONTENTS**

	Pag	je		
	INTRODUCTION	1		
	Special Features	2		
	Parts Check List	3		
	TCC REGULATIONS	4		
	IMPORTANT SAFETY INSTRUCTIONS		7	
	REPLACING THE BATTERY PACK			
	GETTING STARTED			
	WALL MOUNTING			
	THE LCD DISPLAY			
	THE HANDSET LAYOUT		b	
	THE BASE UNIT LAYOUT	5	М	
	QUICK REFERENCE GUIDE			
	BASIC OPERATION	<b>(R</b> )	20	
	ADVANCED FUNCTIONS			
	<del>CID With</del> Call Waiting			
	Switching Calls			
	Temporary Tone			
	Programming The Ringer	20 2	น	
	Changing Ringer Types			
	Turning Off The Ringer			
	CLR/DEL Key Function			
	Advanced Dialing	2.	23	
			7 A.	
	MEMORY DIALING		1	
	Storing Speed Dial Numbers Dialing From Memory		5	
	Changing Stored Numbers			
	Deleting Stored Numbers			
	Storing Special Codes	25	26	
			-	
	CID-CALLER ID		27	
	CID-CALLER ID	26	27	
	Receiving and Storing Calls			
	Dialing From CID Memory	26	?]	
	Out Of Area Calls			
	"Private" Calls			
	Transmission Error		29	
	Reviewing Numbers	38	30	
	Deleting Numbers	29	30	
	ADDITIONAL OPERATING TIPS	Ð	31	
	MAINTENACE	S.	32	
			-	
0	IN CASE OF DIFFICULTY	22	ود	
	WARRANTY	39		
	·	•	2	
	TECHNICAL SPECIFICATIONS	30	34	
	12 MONTH LIMITED WARRANTY			
			~	

-\$-

A

Ð



## AUDIOVOX COMMUNICATIONS CORP.

555 Wireless Blvd., Hauppauge, New York 11788, 516-233-3300 16808 Marquardt Avenue, Cerritos, California 90701, 562-802-5100 Audiovox Canada 405D Britannia Rd, East, Ste 101, Mississauga Ontario, Canada L4Z3E6, 905-712-9299 Audiovox Pacific Pty Ltd. 110 Rocky Point Road, Kogarah, NSW 2217, Australia, 02-9587-0011 Audiovox Singapore Pte. Ltd. 268 Orchard Road, 107-07, Singapore, 238856,65-733-5902 http:///www.audiovox.com. LTCLL435

91-XXXX-XX-ISSUE 0

DT 921

37

÷

-4-5

-()-

a la

S.Fr.

.....

...

191



5/15/98, 11:13 AM